Test stand

.....

MX-1000N / MV-1000N series

Motorized Test Stand



(Force gauge and speed/length meter are sold separately.)

[Applications]

- Various material testing up to 1000N
 (measuring of tensile strength, compressive strength, shearing strength and etc).
- Analysis of mechanical parts for break point and free fit.

[Features]

- Stable measuring by feed screw features with small step of the travel length.
- Suitable for Imada brand digital and mechanical force gauges.
- Overload protection and force control connecting with digital force gauge (Only for MX series)
- Optional scale unit implements scaling its travel length.



[MX-1000N/MV-1000N series models]

Model	Capacity	Auto cycle	Length/speed meter	Scale unit
MX-1000N	1000N	Yes		
MV-1000N				
MX-1000N-E		Yes	Yes	
MV-1000N-E			Yes	
MX-1000N-S		Yes		Yes
MV-1000N-S				Yes

[MX-1000N/MV-1000N series specifications]

Model	MX-1000N	MV-1000N			
Capacity	1000N				
Stroke	Approx. 400mm				
Feeding method	Feed screw with 4mm lead				
Travel speed	8 to 240 mm/min non-step				
Table	150 x 100 mm, Steel				
Force gauge	Imada mechanical / digital force gauge				
Single/Continuous cycle	Yes				
Overland prestantian		Press and keep button for 2			
Overload protection	Yes *0	seconds so that this machine keeps			
Force control		moving			
Dimensions	See dimensions				
Wight	Approx. 24kg				
Accessories	Grip mount GF-2(with M10/M6 thread)				
Below goodies are optional					
Scale unit	Resolution: 0.01mm				
(option *1)	Zero / Origin				
	EN-00 Speed resolution 1mm/min Length resolution 0.01mm				
Length/speed meter					
(option *2)					
	Zero				


^{*0} Optional cable CB-501 is necessary for connection with force gauge. Some model of force gauge is not compatible with this function.

^{*1} Factory built only for MX/MV-1000N-S

^{*2} Factory built only for MX/MV-1000N-E. See a brochure for EN-00



[Dimensions]



[Note]

- Force gauge is not included with this test stand.
- Various optional attachments are available.
- "Overload protection" does NOT completely avoid every failure of the gauge.
- Please do not apply the load exceeding force of capacity.
- Please avoid rapid temperature change, high humidity, the water, the dust, and the strong shock.
- It may change without a preliminary announcement for improvement etc.



IGNACIO ELLACURÍA, 10-12 TELS. 91 356 22 94 - FAX: 91 355 58 08 28017 MADRID

E-mail: info@tecnimetalsa.com